

Scenix® Porch Windows with Retractable Screens


Determine Your New Porch Design

- How many panels do you need?
 - What are your window sizes?
- Project checklist**
- ✓ Tape Measure
 - ✓ Shims
 - ✓ Screwdriver

COLORS				STANDARD ROUGH OPENING SIZES		CUSTOM ROUGH OPENING SIZES
White	Sandstone	Brown	Black	Available in White	44-1/2"W x 72"H	Available in White, Sandstone, Brown and Black
				44-1/2"W x 84"H	44-1/2"W x 84"H	Widths from 24" to 72"
				56-1/2"W x 72"H	56-1/2"W x 84"H	Heights from 30" to 96"
				68-1/2"W x 72"H	68-1/2"W x 84"H	
				UPGRADE SCREEN*	UPGRADE GLASS*	*Only available on custom sizes
				4-IN-1 Screen	Solarshield Grey Solarshield Bronze	

Do the Math

	Rough Opening Size	
	Width	Height
Example	38-1/2"	52"
Window #1		
Window #2		
Window #3		
Window #4		
Window #5		
Window #6		
Window #7		
Window #8		



4 Easy Steps to Order

1 Measure Width

Measure between the jambs at three points: top, middle and bottom of the window opening. Measure from the surface of the jambs where the window will be mounted. Use the smallest of these three measurements to order the window.

2 Measure Height

Measure from the high point of the sill of your window to the top of the window opening. Make three measurements: one at the left side, one at the center and one at the right side of the window. Use the smallest of these three height measurements to order the window.

3 Measure Depth

There must be at least 2-1/2" of opening depth between the inside window trim and the outside to accommodate the depth of the porch window.

4 Order Your Windows

When placing your order, provide rough opening sizes. For manufacturing purposes, the actual window size will be 1/2" smaller in width and height than the ordered size.

